18. FOLDING TROUBLESHOOTING

If the key fob is not working or has been replaced, then the fob may need pairing with the scooter. To do this, please follow the procedure below .

Step 1: Turn on the scooter.



Step 2: Press the A-Open button on the control panel for 5 seconds and then release it. The buzzer will sound continuously, indicating that the control is ready to pair to the key fob.



Step 3: Press both the A and B buttons on the key fob, at the same time. The buzzer will sound 5 short beeps, indicating that the control has paired with the key fob. The buzzer will then continue to sound.



Step 4: Press the B-Closed button on the control panel to silence the buzzer and complete the pairing sequence.



<u>Key fob and buttons not working</u>

If the folding mechanism is not working when using either the buttons on the tiller or the key fob, then the scooter may have been opened or closed manually and the folding mechanism might need resetting.

1. If the scooter is open, close it manually by lifting on the red lever as shown below:



2. Switch the scooter on and press the B-Close button on the tiller head or key fob remote.
3. When the scooter finishes beeping, press the B-Close button again. The red lever should click in to place when the scooter finishes beeping to confirm the mechanism has reset.

Videos showing the above processes are also available on the Drive DeVilbiss website: **www.drivedevilbiss.co.uk.**